




MISSION[®]
CONTROLS

READ = SUCCEEDED
IGNORE = FAILURE



BASICFAN[™]
SPEED CONTROLLER
6.5A

User Instructions

EN

RU

SQ

PL

LT

NL

FR

DE

IT

ES



BASICFAN™

SPEED CONTROLLER

6.5A

Features:




Fluid-Motion™


- Controls 1 fan
- Manual speed control 0-100%
- Compact design
- Will not obstruct adjacent plug sockets
- Integrated Plug
- CE Certified
- 2 year warranty

Understanding Features - Visit www.missioncontrols.com

What's in the box:



BasicFan™
Speed Controller



User Instructions



Need more assistance?


Scan the QR or visit our website for help:

www.missioncontrols.com




Setting up:


- 1 Plug **BasicFan™** Speed Controller into mains socket.



- 2 Plug fan into the socket of **BasicFan™** Speed Controller.




- 3 Switch on at mains.



How to use:

Control fan speed with dial 1.



Dial 1
(Fan Speed)



BASICFAN™

SPEED CONTROLLER

6.5A

Technical Specifications:

6.5A	220/240V	50Hz	1500W
------	----------	------	-------

Please visit www.missioncontrols.com and navigate to the product page to download the instruction manual in your preferred language.



EN

FR

DE

ES

IT

NL

RU

PL

SQ

LT

www.missioncontrols.com/learn



MISSION® CONTROLS

www.missioncontrols.com